
TEAC

スピーカースタンド
SPEAKER STAND

TA-STD300



取扱説明書
OWNER'S MANUAL

お使いになる前に

ティアック製品をお買い上げいただき、誠にありがとうございます。
ご使用になる前にこの取扱説明書をよくお読みください。また、お読みになったあとは、いつでも見られるところに大切に保管してください。
末長くご愛用くださいますよう、お願い申し上げます。

組み立てを始める前に

- 裏面の安全上の注意を必ずお読みください。
- 組み立て作業をする場所は、カーペットや毛布などを敷いて床や製品を傷つけないようにご注意ください。
- 組み立てる前に、必ず付属品と組立図（下図）を確認してください。

付属品の確認

万一、付属品に不足や損傷がありましたら、お買い上げになった販売店、または弊社 AVお客様相談室（裏面に記載）にご連絡ください。

- 天板 x 2
- 支柱 x 2
- 台座 x 2
- 取扱説明書（本書） x 1
- ネジ（30mm） x 12 ※1
- ワッシャー x 12 ※1
- ラバークッション x 8
- 六角レンチ x 1
- ネジ（25mm） x 6 ※2
- ワッシャー x 6 ※2
- コルクシート x 6 ※2

※1 天板/台座固定用　※2 スピーカー固定用

Before use

Thank you for choosing TEAC.
Read this manual carefully to get the best performance from this unit.
After reading it, keep it in a safe place for future reference.

Before assemble

- Please read the following instructions and cautions carefully in order to prevent injury to yourself or others and damage to property.
- Assemble them on a carpet or a blanket in order to prevent floor and the product.
- Check the parts list and the assembly drawings shown below.


Included Items


Check to be sure the box includes all the supplied accessories shown below. Please contact the store where you purchased if any of these accessories are missing or have been damaged during transportation.

- Top Plate x 2
- Pillar x 2
- Base x 2
- Owner's Manual (this document) x 1
- Screw (30mm) x 12 *1
- Washer x 12 *1
- Rubber Cushion x 8
- Screw (25mm) x 6 *2
- Washer x 6 *2
- Cork Sheet x 6 *2
- Hex Wrench x 1


*1 Used for Top Plate and Base　*2 Used for Speakers

1





2



安全にお使い頂くために 製品を安全に正しくお使い頂き、あなたや他の人々への危害や財産への損害を未然に防ぐために、以下の注意事項をよくお読みください。

⚠ 警告 以下の内容を無視して誤った取り扱いをすると、人が死亡または重傷を負う可能性が想定される内容を示しています。

分解禁止	**この機器を分解、改造しない。** 変形や破損、転倒などを引き起こす原因になります。
禁止	**廃棄する時は、自分で焼却しない。** 有害ガスが発生するなど、周囲に危険をおよぼすことがあります。必ずお住まいの自治体の指示に従って処分してください。

⚠ 注意 以下の内容を無視して誤った取り扱いをすると、人が傷害を負う可能性が想定される内容および物的損害のみの発生が想定される内容を示しています。

禁止	**スピーカー・スタンド以外の目的に使用しない。** 怪我や故障・破損の原因になります。
	スピーカーがガタつかないように確実に設置する。 **ネジのゆるみによるガタつきが生じた場合は締め直す。締め直しても直らない場合は、使用を中止する。** 破損したり、転倒で怪我をする恐れがあります。
	分解したり部品を外したまま使用しない。 破損したり、転倒で怪我をする恐れがあります。
	製品に足をかけたり腰掛けたりしない。小さなお子様がいる場所では、ぶら下がったり遊びに使わせない。 **ぐらついた台の上や傾いた所など不安定な場所に置かない。** 転倒して怪我をする恐れがあります。
	直射日光やストーブなど熱が直接当たる場所や、湿気・乾燥の著しい場所では使用しない。 変色や変形・そりなどの原因になります。
指示	**移動させる場合は接続された機器などを取り外してから、注意して行う。** 転倒して怪我をしたり、機器を破損する恐れがあります。

ティアック株式会社 〒206-8530 東京都多摩市落合 1-47 http://teac.jp

この製品のお取り扱い等についてのお問い合わせ
AVお客様相談室 〒206-8530 東京都多摩市落合 1-47
ナビダイヤル **0570-000-701** ナビダイヤルがご利用頂けない場合は、電話：042-356-9235 / FAX：042-356-9242
受付時間は、9:30～12:00 / 13:00～17:00です。（土・日・祝日・弊社指定休日を除く）

故障・修理や保守についてのお問い合わせ
ティアック修理センター 〒358-0026 埼玉県入間市小谷田858
ナビダイヤル **0570-000-701** ナビダイヤルがご利用頂けない場合は、電話：04-2901-1033 / FAX：04-2901-1036
受付時間は、9:30～17:00です。（土・日・祝日・弊社指定休日を除く）

● ナビダイヤルは一般電話・公衆電話からは市内通話料金でご利用になれます。● 住所や電話番号は、予告なく変更する場合があります。あらかじめご了承ください。

お手入れ

表面が汚れたときは柔らかい布で拭いてください。
目の粗いぞうきんや化学ぞうきん、ベンジン、シンナー、研磨剤などで拭かないでください。表面を傷める原因となります。

仕様

最大外形（幅、高さ、奥行き） ..... 320 x 620 x 320 mm
質量 5.9kg/台
適用機種（2016年3月現在） ..... S-300HR、S-300NEO

Maintenance

When the surface becomes dirty, use a soft dry cloth to wipe it clean.
Do not wipe it with finemeshed cleaning cloths, chemical cleaning cloths, thinner, abrasives or similar materials Doing so could damage the surface.

Specifications

Overall Dimensions (W x H x D) ..... 320 x 620 x 320 mm / 12.6" x 24.4" x 12.6"
Weight (per piece) ..... 5.9kg / 13.0 lbs.
Compatible Speakers (as of March 2016) S-300HR, S-300NEO
Not every model available in every country.

⚠ CAUTION

Safety Instructions

- This equipment is exclusively designed for the compatible speakers shown above. Do not use it for other speakers or other purposes.
- Do not install in an unstable location, such as on a slope, or in a location with frequent vibrations.
- Do not install in a location that becomes hot, including places exposed to direct sunlight or near heating equipment.
- Do not install in a location that becomes humid, including in a bath room or near humidifiers. Indoor use only.

Modification prohibited

- Never modify this equipment.
- If repair or modification of this equipment is conducted by anyone other than one of our designated service providers, the warranty will be invalidated immediately.
- If this equipment is broken or damaged by repair or modification conducted by anyone other than one of our designated service providers, our company will bear no responsibility even if harm occurs to people or property.

TEAC CORPORATION	1-47 Ochiai, Tama-shi, Tokyo 206-8530, Japan Phone: +81-42-356-9156
TEAC AMERICA INC.	1834 Gage Road, Montebello, California 90640 U.S.A. Phone +1-323-726-0303
TEAC AUDIO EUROPE	Gutenbergstr. 3, 82178 Puchheim, Germany Phone +49-8142-4208-141

0216 P/N 3-530008-033020